

INSTALLATION INSTRUCTIONS

4241 B - PS

WRANGLER (EXCL. UNLIMITED & UNLIMITED RUBICON) 87 - 06

Parts List:

QTY	(1) Hardware kit including :
(1) Side bar set (Driver & Passenger)	(4) 1/2 x 1 1/2" Hex head bolts
(4) Mounting brackets	(4) 1/2" Flat washers
	(4) 1/2" Lock washers

Tools required:


3/4" Socket	3/4" Wrench
5/8" Socket	Ratchet

Instructions:

Approximated installation time: 30 min.

1. Read and understand instructions completely before beginning installation.
2. Side bar set consists of a driver and passenger side. Be sure to determinate the correct side before installation.
3. Loosen the body mounting bolts from mounts located under the cab of the vehicle.
4. Place the front/rear mounting brackets up to the body mounts and retighten. Hand tighten at this moment. Leave loose.
5. Place the sidebar up to the front and rear mounting brackets and bolt to the mounting brackets using the 1/2 x 1 1/2" hex head bolts, flat and lock washers. Leave loose.
6. Make any final adjustments to the alignment of the sidebar and tighten all bolts. Repeat for the opposite side.
7. You may need to periodically re-tighten the bolts.

Assembly Diagram :



Cleaning and care instructions :

Protect the finish with a non-abrasive automotive wax, (e.g. Pure Carnauba) on a regular basis. The use of any soap, polish, or wax that contains an abrasive is detrimental to the finish, as the compounds scratch the finish and cause corrosion.