

# GO RHINO!

## PRODUCTS®

### DOMINATOR

#### D2

REV/03-12

## DOMINATOR 2 SERIES SIDESTEPS

### ASSEMBLY & INSTALLATION INSTRUCTIONS

PART NO. D24040 99-07 (classic) GM EXTENDED CAB

**Do not attempt to install this product on any vehicle other than the one it is designed for and listed above!**

QTY	PARTS DESCRIPTION	QTY	PARTS DESCRIPTION
12	1/4" X 3/4" SELF TAPPING HEX BOLTS	24	3/8" X 1" HEX BOLTS
24	3/8" HEX NUTS	6	C99 MOUNTING BRACKETS
24	3/8" LOCK WASHERS	1	D24040P PASSENGER SIDESTEP
48	3/8" FLAT WASHERS	1	D24040D DRIVER SIDESTEP

## INSTALLATION INSTRUCTIONS

Read the instructions completely before you begin the installation.


If your vehicle is equipped with factory running boards, remove the boards, brackets and fasteners.

This installation uses (3) mounting brackets per side, and requires drilling (2) holes in the lower body pinch mold for each bracket.

It is the installer's responsibility to confirm all measurements and that there are no obstructions such as brake, fuel or electrical lines before drilling.

**Step 1.** Beginning with the passenger side measure rearward from the front fender bolt (refer to diagram for dimensions) and scribe (6) vertical lines on the body pinch mold.






**Step 2.** Measure up from the bottom edge of the pinch mold 7/16" and scribe intersecting lines.



**Step 3.** Confirm the measurements, center punch and drill 3/8" holes through the body pinch mold. Repeat the above procedure for the driver side.



(OPTIONAL) Use the holes in the upper flange of the mounting brackets as a guide and drill 3/16" holes in the under side of the body. Attach the flange to the body using the 1/4" x 3/4" self-tapping bolts supplied.

**\*\*WARNING:** *There is a wiring harness located inside the body area to be drilled. It is the installer's responsibility to use caution when drilling and prevent the drill or bolts from coming in contact with the wiring harness. Failure to do so may damage the vehicles electrical system.*

**Step 4.** Loosely attach the flange of the mounting brackets to the bottom of the lower body pinch mold using the 3/8" x 1" hex bolts, flat washers, lock washers and nuts as shown.







**Step 5.** Position the passenger sidestep up to the mounting brackets and loosely attach it to the brackets using the 3/8" x 1" hex bolts, flat washers, lock washers and nuts.



**Step 6.** Align sidestep with the body and then tighten all mounting bracket and sidestep nuts and bolts.  
**Step 7.** Repeat the above installation steps to install the driver side mounting brackets and sidestep.

## Dominator II (one piece)

- Application specific installation brackets make for faster, easier installation
- Patented step and mounting system allow easier, safer entry and exit
- No drilling required on most models and body lift kit compatible
- Cab length
- 2" round bars with aluminum step pads
- Will ship UPS
- Available in black powder coat finish with a limited 5-year warranty
- Polished stainless steel with a limited lifetime warranty
- U.S. Patent No. 6,588,783 - 6,874,801 and other patents pending

Warranty: Go Rhino! Products® warrants its products to be free from defects in materials and workmanship. This limited warranty extends for 5 years/50,000 miles (whichever comes first) for black, 5 years/50,000 miles (whichever comes first) for chrome and a limited lifetime for polished stainless from the date of purchase for parts purchased after April 2004. Warranty claims must be accompanied with original invoice and photos. It is the customer's responsibility to protect the finish with regular applications of a nonabrasive polish that is compatible with the product's finish. This warranty covers the cost of the product only and does not include the cost of removal, installation or shipping. This warranty is void if the product shows signs of alteration, misuse, mishandling, improper care, neglect, improper application, and/or damages improper installation. This warranty provides a one-time replacement on workmanship if all of the above conditions are met.

Liability: Go Rhino! Products® Grille and Brush Guards are designed to enhance the styling of the vehicle only; they are not intended as collision protection bumpers. Go Rhino! Products'® liability is limited to the repair or replacement of the defective part(s) made by GoRhino! products®. The item(s) will be subjected to inspection by Go Rhino! Products®. Part(s) that in our opinion were damaged by incorrect fitting, neglect or improper use will not be replaced or repaired. Go Rhino! Products® reserves the right to change specifications, terms, conditions and prices of items shown in this catalog without notice.

**Please do not return this product to place of purchase.**

**If you have defective, missing or damaged parts or need assistance, please contact *Go Rhino Products* for fast, friendly customer service at: 1-888-427-4466 or email:**

**[warranty@gorhino.com](mailto:warranty@gorhino.com)**