# DOMINATOR

# DOMINATOR SERIES SIDESTEPS

ASSEMBLY & INSTALLATION INSTRUCTIONS PART NO. D24097 02-08 DODGE RAM QUAD CAB

Do not attempt to install this product on any vehicle other than the one it is designed for and listed above!

#### QTY PARTS DESCRIPTION

- 12 3/8" X 2" HEX BOLTS
- 24 3/8" HEX NUTS
- 24 3/8" LOCK WASHERS
- 48 3/8" FLAT WASHERS

### QTY PARTS DESCRIPTION

- 12 3/8" X 1" HEX BOLTS
- 4 D02 FRONT AND REAR MOUNTING BRACKETS
- 2 D03 CENTER MOUNTING BRACKETS
- 1 D24097P PASSENGER SIDESTEP
  - D24097D DRIVER SIDESTEP

## INSTALLATION INSTRUCTIONS

1

Read the instructions completely before you begin the installation.

If your vehicle is equipped with factory running boards, remove the boards, brackets and fasteners. This installation uses (3) mounting brackets per side, and requires drilling (2) holes in the lower body pinch mold for each bracket.

It is the installer's responsibility to confirm all measurements and that there are no obstructions such as brake, fuel or electrical lines before drilling.

**Step 1.** Beginning with the passenger side measure reward from the front fender bolt (refer to diagram for dimensions) and scribe (6) vertical lines on the body pinch mold.







**Step 3.** Confirm the measurements, center punch and drill 3/8" holes through the body pinch mold. Repeat the above steps for the driver side.



**Step 4.** Loosely attach the mounting brackets to the body pinch mold using the 3/8" x 2" hex bolts, flat washers, lock washers and hex nuts as shown.





**Step 5.** Position the passenger sidestep up to the mounting brackets and loosely attach it to the brackets using the 3/8" x 1" hex bolts, flat washers, lock washers and hex nuts.



**Step 6.** Align sidestep with the body and then tighten all mounting bracket and sidestep nuts and bolts. **Step 7.** Repeat the above steps to install the driver side mounting brackets and sidestep.