

**Installation Instructions**  
**Dominator D3 Side Steps Part # D360771**

**07-10 Chevrolet Silverado & GMC Sierra 2500HD, 3500HD Crew Cab 6.5' Bed (Gas & Diesel)**  
**11-15 Chevrolet Silverado & GMC Sierra 2500HD, 3500HD Crew Cab 6.5' Bed (Gasoline)**  
Do not attempt to install this product on any vehicle other than the one listed above!

**Parts List**

<b><u>QTY</u></b>	<b><u>Part Description</u></b>	<b><u>QTY</u></b>	<b><u>Part Description</u></b>
12	M8 x 25mm Hex Bolt	24	3/8" Flat Washer
4	M8 U-Nut	12	3/8" Hex Nut
6	M8 Hex Nut	3	Driver Bracket (C0751)
18	5/16" Flat Washer	3	Passenger Bracket (C0752)
12	5/16" Lock Washer	1	Passenger Side Step (D360771P)
12	3/8" x 1 1/4" Hex Bolt	1	Driver Side Step (D360771D)
12	3/8" Lock Washer		

**Tool Required:**

9/16" & 13mm Socket  
9/16" & 13mm Wrench  
Ratchet & Ratchet Extension  
Tape Measure


**Approximate installation time: 60min**

Read the installation instructions completely and verify that all of the parts listed are accounted for. If you have defective, missing or damaged parts or need assistance, please contact *Go Rhino Products* for fast, friendly customer service at: 1-888-427-4466 or email: [warranty@gorhino.com](mailto:warranty@gorhino.com)


**Installation**

This installation uses three brackets per side. Begin by installing the driver side front bracket.


**Step-1** Measure from the front fender bolt rearward approximately 14" and locate the hole in the body pinch mold and the M8 threaded insert in the rocker panel, (**Photo 1 & 2**).



**Step-2** Attach one of the driver side brackets to the pinch mold using (1) M8 hex bolt, (2) 5/16" flat washers, (1) 5/16" lock washer and (1) M8 hex nut, and to the rocker panel using (1) M8 hex bolt, (1) 5/16" lock washer and (1) 5/16" flat washer. Leave the nut and bolts loose for final adjustment, **(Photo 3)**.



**Step-3** Install the driver side center bracket by measuring from the front fender bolt reward approximately 58 7/8" and locate the hole in the body pinch mold and the plastic plug in the rocker panel, **(Photo 4)**. Remove the plastic plug from the rocker panel and install (1) M8 U-Nut in the rocker panel, **(Photo 5)**.



**Step-4** Attach one of the driver side brackets to the rocker panel using the U-Nut, (1) M8 hex bolt, (1) 5/16" lock washer and (1) 5/16" flat washer, and to the pinch mold using (1) M8 hex bolt, (2) 5/16" flat washers, (1) 5/16" lock washer, and (1) M8 hex nut. Leave the nut and bolts loose for final adjustment, **(Photo 6)**.



**Step-5** Install the driver side rear bracket by measuring from the front fender bolt reward approximately 75 1/8" and repeat the above steps.

**Step-6** Attach the driver side step to each bracket using (2) 3/8" x 1 1/4" hex bolts, (4) 3/8" flat washers, (2) 3/8" lock washers and (2) 3/8" hex nuts, **(Photo 7)**.

**Step-7** Align the side step with the vehicle and tighten all bracket and side step nuts and bolts, **(Photo 8)**. Repeat the above steps to install the driver side brackets and side step. Remember to check and retighten the nuts and bolts every six months.

